

Digital Timer H5CX-□-N

Ultra-compact Timer Provides Advanced Functions and Security Settings.

Basic Features

- Short body with depth of only 59 mm (for 24-VAC / 12 to 24-VDC Models with Screw Terminals). *1
- Character height of 12 mm for better readability (on models with 4 digits).
- The present value display characters can be switched between red, green, and orange. *2

Safety and Reliability

- Power supply circuit and input circuits are isolated for safety and reliability. *3
- New set value limit and output counter functions have been added.

- Front Panel can be changed to white or light gray. *5
- Models with instantaneous contact output added to the series.
- *1. For 100 to 240 VAC Models with Screw Terminals 78 mm, Models with Sockets: 63.7 mm (case dimension).
 The H5CX-A11, H5CX-L8 and H5CX-B Timers have only red characters.

- *3. Specifications: 100 to 240 VAC

 *4. The value of the output counter can only be monitored. It cannot be reset.
- Replacement Front Panels sold separately



For the most recent information on models that have been certified for safety standards, refer to your OMRON website



Refer to "Safety Precautions" on page 41.


Features

Basic Features Ultra Short Body

The body depth has been greatly reduced. Helps in making thinner control panels. (Models with Screw Terminals)

24-VAC / 12 to 24-VDC Models with Screw Terminals: 59 mm 100 to 240-VAC / VDC Models with Screw Terminals: 78 mm * Models with Sockets: 63.7 mm (case dimension)

The shortest body for a timer with isolated power supply and input circuits and a maximum ambient temperature of 55°C (according to OMRON investigation in June 2009).



Easier to Read

For better readability, the character height for the present value display is 12 mm (on models with 4 digits), the largest class in the industry. The wide viewing angle and brightness provide excellent visibility.

The number of display segments has also been increased to make settings easier to understand, and the present value display can be switched between red, green and orange so that output status can be seen from a distance.

Model with 4 Digits Model with 6 Digits







(Display example)

Note: The H5CX-A11 and H5CX-L8 Timers have only red characters.

The Easiest Operation

Operation is simplified by the Up/Down Keys for each digit on 4-digit models and Up Keys for each digit on 6-digit models.






Safety and Reliability Isolated Power Supply and Input Circuits *1

Power supply circuit and input circuits are isolated for safety and reliability.

Previous non-isolated timers had wiring restrictions and could be damaged if wired incorrectly. The New H5CX removes these worries.



*1. New Models (H5CX-□-N) with 100 to 240-VAC specifications.

Set Value Limit

You can set an upper limit for the set value to prevent unexpected operation of output devices caused by setting mistakes.




Output Counter

An output counter counts the number of times that the output turns ON. (An alarm can be set and the value of the output counter can be monitored, Unit: 1,000 operations.) This counter is useful in managing the service life of the Timrrer or the load.

Other Features

Change the Front Panel Color

The Front Panel can be replaced with an optional Front Panel (order separately) with a different color to match the installation site. Select from black, white, and light gray.



Models with Instantaneous Contact Output

Models with instantaneous contact outputs have been added to the lineup for use with self-holding circuits and as auxiliary relays. These models are also convenient when replacing analog timers.

Universal NPN/PNP Input

DC 2-wire sensors can be connected for a wide range of input devices.

Waterproof, Dust-proof Structure (UL508 Type 4X and IP66)

Worry-free application is possible in locations subject to water. **Note:** When the Y92S-29 Waterproof Packing is used.

Key Protection

Select from any of seven protection patterns. Use the best one for the application.

New Modes

Modes, such as a stopwatch mode (Mode S), have been added. Select any of 15 modes.

Model Number Structure

Model Configuration

	_	H5CX Series				
		Ī				
Туре		Standard Type H5CX-A Series		Economy Type H5CX-L Series		Six-digit Type
		234 1234 1234				[2] 1/5 [0] [2] 1/5 [0] [2] 1/4 [0]
Model		H5CX-A□-N	H5CX-A11□-N	H5CX-L8□-N	H5CX-L8E□-N	H5CX-BWSD-N
	Timer	Yes		Yes		No
Function	Twin timer	Yes		Yes		No
	Two-stage settings/ forecast output	No		No		Yes
Operating modes		Timer Mode: 11 modes Twin Timer Mode: 4 modes		les	Timer Mode : 4 modes Twin Timer Mode : 2 modes	Timer Mode: 2 modes
Input		NPN/PN	NP input	NPN input None		NPN/PNP input
External	connections	Screw terminal block	11-pin socket	8-pin socket		Screw terminal block
Present value display character color		Red, green, or orange	Red			
Number of display digits		4				6
Instantaneous contacts		·	None		Provided	None
Gate input		Supp	orted	Not su	pported	Supported
DIP switch settings		Prov	ided	No	one	Provided
Power su	pply voltage		100 to 240 VAC or 2	4 VAC/12 to 24 VDC		12 to 24 VDC

Model Number Legend (Not all possible combinations of functions are available.)

H5CX- U U U U -N 1 2 3 4 5

1. Type Classifier

Symbol	Meaning
A	Standard type
В	6-digit type
L	Economy type

2. External Connections

Symbol	Meaning
None	Screw terminals
8	8-pin socket
11	11-pin socket

3. Settings

Symbol	Meaning
None	One stage
W	Two stages

4. Output type

Symbol	Meaning		
None	Contact output (time-limit SPDT)		
E	Contact output (time-limit SPDT + instantaneous SPDT) *		
S	Transistor output		

^{5.} Supply voltage

Symbol	Meaning		
None	100 to 240 VAC 50/60 Hz		
D	12 to 24 VDC/24 VAC 50/60 Hz *		
The HECV DWCD N is evallable only for 12 to 24 VDC			

Note: Estimates can be provided for coatings and other specifications that are not given in the datasheet. Ask your OMRON representative for details.

Ordering Information

List of Models

Туре	Time specifications	Operating modes	External connections	Inputs	Outputs	Supply voltage	Models	
		Timer Mode A: Signal ON Delay I A-1: Signal ON Delay II A-2: Power ON Delay I A-3: Power ON Delay II	Screw terminals	Signal, Reset,	Contact output (time-limit SPDT)	100 to 240 VAC	H5CX-A-N	
						12 to 24 VDC/ 24 VAC	H5CX-AD-N	
					Transistor output (SPST)	100 to 240 VAC	H5CX-AS-N	
H5CX-A						12 to 24 VDC/ 24 VAC	H5CX-ASD-N	
посх-я		b: Repeat cycle 1		Gate (NPN/ PNP inputs)	Contact output	100 to 240 VAC	H5CX-A11-N	
	0.001 to 9.999 s	b-1: Repeat cycle 2 d: Signal OFF Delay E: Interval	11-pin socket		(time-limit SPDT)	12 to 24 VDC/ 24 VAC	H5CX-A11D-N	
	0.001 to 99.99 s	F: Cumulative	11-pin socket		Transistor output (SPST)	100 to 240 VAC	H5CX-A11S-N	
	0.1 to 999.9 s 1 to 9999 s	Z: ON/OFF-duty-adjustable flicker S: Stopwatch				12 to 24 VDC/ 24 VAC	H5CX-A11SD-N	
	- 1 s to 99 min 59 s 0.1 to 999.9 min 1 to 9999 min 1 min to 99 h 59 min 0.1 to 999.9 h 1 to 9999 h	Twin Timer Mode toff: Flicker OFF Start 1 ton: Flicker ON Start 1 toff-1: Flicker OFF Start 2 ton-1: Flicker ON Start 2	8-pin socket	Signal, Reset (NPN inputs)	Contact output (time-limit SPDT)	100 to 240 VAC	H5CX-L8-N	
						12 to 24 VDC/ 24 VAC	H5CX-L8D-N	
					Transistor output (SPST)	100 to 240 VAC	H5CX-L8S-N	
						12 to 24 VDC/ 24 VAC	H5CX-L8SD-N	
H5CX-L		Timer Mode A-2: Power ON Delay I b: Repeat cycle 1 E: Interval Z: ON/OFF-duty-adjustable flicker		8-pin socket	8-pin socket	Contact output (time-limit SPDT + instantaneous SPDT)	100 to 240 VAC	H5CX-L8E-N
		Twin Timer Mode toff: Flicker OFF Start 1 ton: Flicker ON Start 1			Models with instantaneous contact outputs	12 to 24 VDC/ 24 VAC	H5CX-L8ED-N	
Н5СХ-В	0.01 to 9999.99 s 1 s to 99 h 59 min 59 s 0.1 to 99999.9 min 0.1 to 99999.9 h	A: Signal ON Delay I F-1: Cumulative	Screw terminals	Signal, Reset, Gate (NPN/ PNP inputs)	Transistor output (DPST)	12 to 24 VDC	H5CX-BWSD-N	

Note: 1. The functions that are provided depend on the model. Check detailed specifications before ordering.2. Refer to page 33 and later for information on H5CX-B Timers (6-digit display).

^{*} Can be used as a time-limit DPDT output.

Accessories (Order Separately)

Front Panels (Replacement Parts)

Models	Color	Applicable Timers	Page
Y92P-CXT4G	Light gray (5Y7/1)		
Y92P-CXT4S	White (5Y9.2 / 0.5)	Four-digit models	12
Y92P-CXT4B	Black (N1.5)		

Note: 1. You can change the color of the front panel when mounting the Timer. The Timer is shipped with a black (N1.5) Front Panel.

2. "TIMER" is printed on the front of Replacement Front Panels.

Soft Cover

Models	Remarks	Page
Y92A-48F1		12

Hard Cover

Models	Remarks	Page
Y92A-48		12

Flush Mounting Adapter

Models	Remarks	Page
Y92F-30	Included with models with terminal blocks.	
Y92F-45	Use this Adapter to install the Timer in a cutout previously made for a DIN 72 x 72 mm device (panel cutout: 68 x 68 mm).	12
Y92F-38	Use for replacement of the 81-dia. hole device (H3AM).	

Waterproof Packing

Models Remarks		Page
Y92S-29	Included with models with terminal blocks.	12

Connection Sockets

Models	Туре	Connectable Timers	Remarks	Page
P2CF-08	Front Connecting Socket			
P2CF-08-E	Front Connecting Socket (Finger-safe Type)	H5CX-L8□	Round crimp terminals cannot be used on Finger-safe Sockets. Use forked crimp terminals.	
P2CF-11	Front Connecting Socket			13
P2CF-11-E	Front Connecting Socket (Finger-safe Type)	H5CX-A11□	Round crimp terminals cannot be used on Finger-safe Sockets. Use forked crimp terminals.	
P3G-08	Pauls Connecting Coalset	H5CX-L8□	A Y92A-48G Terminal Cover can be used with the	
P3GA-11	Back Connecting Socket	H5CX-A11□	Socket to create a finger-safe construction.	

Terminal Covers for P3G-08 and P3GA-11 Back-connecting Sockets

Models	Remarks	Page
Y92A-48G		14

H5CX-A□-N/-L□-N Digital Timers

- Switch the display color
 * between red, green, and orange to see the output status from a distance.
- Up/Down Keys for each digit enable easy operation.
- Cyclic control is easy with the Twin Timer and Variable ON/OFF Duty modes.
- ***** Not supported by the H5CX-A11 \square or H5CX-L8 \square .





For the most recent information on models that have been certified for safety standards, refer to your OMRON website.

Specifications

Ratings

Item	Models	H5CX-A□-N	H5CX-A11□-N	H5CX-L8□-N	
Classific	ation	Standard Type		Economy Type	
	Power supply voltage *1	• 100 to 240 VAC 50/60 Hz • 12 to 24 VDC/24 VAC 50/60 Hz			
Ratings	Operating voltage fluctuation range	85% to 110% of rated supply voltage (90%			
	Power consumption	Approx. 6.2 VA at 100 to 240 VAC, Approx	c. 5.1 VA/2.4 W at 24 VAC/12 to 24 VDC *2		
Mountin	g method	Flush mounting	Flush mounting, surface mounting, DIN tra	ack mounting	
External	connections	Screw terminals	11-pin socket	8-pin socket	
Degree o	of protection	IEC IP66, UL508 Type 4X (indoors) for par	nel surface only and when Y92S-29 Waterp	roof Packing is used	
Digits		4 digits			
Time rar	nges		to 999.9 s, 1 s to 9999 s, 1 s ti 99 min 59 s nin to 99 h 59 min, 0.1 h to 999.9 h, 1 h to 9		
Timer m	ode	Elapsed time (Up), remaining time (Down)	(selectable)		
	Input signals	Signal, Reset, Gate		Signal, Reset (no inputs on models with instantaneous contact outputs)	
Inputs	Input method	No-voltage (NPN) input/voltage (PNP) input (switchable) No-voltage Input ON impedance: $1 \text{ k}\Omega$ max. (Leakage current: 12 mA when 0Ω) ON residual voltage: 3 V max. OFF impedance: $100 \text{ k}\Omega$ min. Voltage Input High (logic) level: $4.5 \text{ to } 30 \text{ VDC}$ Low (logic) level: $0 \text{ to } 2 \text{ VDC}$ (Input resistance: approx. 0 constant) No-voltage Input ON impedance: $0 \text{ to } 2 \text{ voltage}$ (Leakage current: 0 No constant) No-voltage Input ON impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant (Leakage current: 0 No constant) No impedance: 0 No constant No impedance: $0 No con$			
	Signal, reset, gate	Minimum input signal width: 1 or 20 ms (se			
Reset sy	stem	Power reset (depending on output mode),	external reset, manual reset, automatic rese	et (depending on output mode)	
Power re	eset	Minimum power-opening time: 0.5 s (exception)	ot for A-3, b-1, F, ton-1, and toff-1 mode)		
Reset vo	oltage	10% max. of rated supply voltage			
Sensor v	waiting time	250 ms max. (Control output is turned OFF	and no input is accepted during sensor wa	aiting time.)	
	Output modes	A: Signal ON Delay I, A-1: Signal ON Delay Delay II, b: Repeat Cycle 1, b-1: Repeat C Cumulative, Z: ON/OFF-duty-adjustable flic ton: Flicker ON Start 1, toff-1: Flicker OFF	ycle 2, d: Signal OFF Delay, E: Interval, F: cker, S: Stopwatch, toff: Flicker OFF Start 1,	Models with Instantaneous Contact Output A-2: Power ON Delay I, b: Repeat Cycle 1, E: Interval, Z: ON/OFF-duty-adjustable flicker, toff: Flicker OFF Start 1, ton: Flicker ON Start	
Output	One-shot output time	0.01 to 99.99 s			
	Control output	Models with Contact Outputs 5 A at 250 VAC/30 VDC, resistive load (cos =1) Minimum applied load: 10 mA at 5 VDC (failure level: P, reference value) Contact materials: AgSnIn Transistor output: NPN open collector, 100 mA at 30 VDC max., residual voltage: 1.5 VDC max. (Approx. 1 V), Leakage current: 0.1 mA max.			
7-segment, negative transmissive LCD; Present value: 12-mm-high characters, (switchable between red, green, and orange) Set value: 6-mm-high characters, green 7-segment, negative transmissive LCD; Present value: 12-mm-high characters, red Set value: 6-mm-high characters, green		d			
Memory	backup	EEPROM (overwrites: 100,000 times min.)	that can store data for 10 years min.		
	ng temperature range		ounted side by side) (with no icing or conder	nsation)	
Storage	temperature range	-25 to 70°C (with no icing or condensation	- n)		
Operatin	ng humidity range	25% to 85%			
Case co	lor	Black (N1.5) (Optional Front Panels are available to change the Front Panel color to light gray or white.)			
Attachm	ents	Waterproof packing, flush mounting adapter, label for DIP switch settings	Label for DIP switch settings		

*1. Do not use the output from an inverter as the power supply. The ripple must be 20% maximum for DC power.
*2. Inrush current will flow for a short time when the power supply is turned ON. Inrush Current (Reference Values)

Voltage	Applied voltage	Inrush current (peak value)	Time
100 to 240 VAC	264 VAC	5.3 A	0.4 ms
12 to 24 VDC/24 VAC	26.4 VAC	6.4 A	1.4 ms
12 to 24 VDO/24 VAC	26.4 VDC	4.4 A	1.7 ms


***3.** The display is lit only when the power is ON. Nothing is displayed when power is OFF.

Characteristics

Accuracy of operating time and setting error (including temperature and voltage influences)		Power-ON start: ±0.01% ±50 ms max. (See note 1.) Signal start: ±0.005%±30 ms max. (See note 1.) Signal start for transistor output model: ±0.005%±3 ms max. (See note 1 and 2.) If the set value is within the sensor waiting time at startup the control output of the H5CX will not turn ON until the sensor waiting time passes. Note: 1. The values are based on the set value. 2. The value is applied for a minimum pulse width of 1 ms.		
Insulation resistance		$100~M\Omega$ min. (at 500 VDC) between current-carrying terminal and exposed non-current-carrying metal parts, and between non-continuous contacts		
Dielectric strength		2,000 VAC, 50/60 Hz for 1 min between current-carrying metal parts and non-current-carrying metal parts 2,000 VAC, 50/60 Hz for 1 min between power supply and input circuits for the models other than H5CX-□D-N and H5CX-L8E□-N 1,000 VAC, 50/60 Hz for 1 min between control output, power supply, and input circuits (for the models other than H5CX-L8E□-N) for H5CX-□SD-N 2,000 VAC, 50/60 Hz for 1 min between control output, power supply, and input circuits (for the models other than H5CX-L8E□-N) for other models 1,000 VAC, 50/60 Hz for 1 min between non-continuous contacts		
Impulse withstand voltage		5 kV (between power terminals) for 100 to 240 VAC, 1 kV for 24 VAC/12 to 24 VDC 5 kV (between current-carrying terminal and exposed non-current-carrying metal parts) for 100 to 240 VAC 1.5 kV for 24 VAC/12 to 24 VDC		
Noise immunity	,	±1.5 kV (between power terminals) and ±600 V (between input terminals), square-wave noise by noise simulator (pulse width: 100 ns/ 1 µs, 1-ns rise)		
Static immunity	,	Malfunction: 8 kV Destruction: 15 kV		
Vibration	Destruction	10 to 55 Hz with 0.75-mm single amplitude each in three directions for 2 h each		
resistance	Malfunction	10 to 55 Hz with 0.35-mm single amplitude each in three directions for 10 min each		
Shock	Destruction	300 m/s ² in three directions, three cycles		
resistance	Malfunction	100 m/s ² in three directions, three cycles		
Life	Mechanical	10,000,000 operations min. (under no load at 1,800 operations/h and ambient temperature of 23°C)		
expectancy	Electrical	100,000 operations min. (5 A at 250 VAC, resistive load at 1,800 operations/h and ambient temperature of 23°C) *		
Weight		Approx. 115 g (Timer only)		

Refer to Life-test Curve.

Life-test Curve (Reference Values)



A maximum current of 0.15 A can be switched at 125 VDC ($\cos\phi$ =1) and a maximum current of 0.1 A can be switched if L/R is 7 ms. In both cases, a life of 100,000 operations can be expected.

Applicable Standards

Approved safety standards	UL508/Listing, UL508 Type 4X for indoor use (enclosure rating), CSA C22.2 No. 14 *1, conforms to EN61812-1 (Pollution degree 2/overvoltage category III) B300 PILOT DUTY 1/4 HP 120 VAC, 1/3 HP, 240 VAC, 5 A resistive load VDE0106/P100 CCC: GB/T 14048.5 Pollution degree 2, Overvoltage category III *2,*3		
EMC	(EMI) Emission Enclosure: Emission AC mains: (EMS) Immunity ESD: Immunity RF-interference: Immunity Burst: Immunity Surge: Immunity Conducted Disturbance: Immunity Voltage Dip/Interruption:	EN61812-1 EN55011 Group 1 class A EN55011 Group 1 class A EN61812-1 IEC61000-4-2 IEC61000-4-3 IEC61000-4-5 IEC61000-4-6 IEC61000-4-6 IEC61000-4-11	

^{*1.} The following safety standards apply to models with sockets (H5CX-A11□ or H5CX-L8□). cUL (Listing): Applicable when an OMRON P2CF (-E) Socket is used. cUR (Recognition): Applicable when any other socket is used.
*2. Excluding the H5CX-ASD-N/-A11SD-N/-L8SD-N.
*3. CCC certification requirements

Rated operating voltage Ue Rated operating current le	Contact Output: AC-15: Ue: 250 VAC, Ie: 3 A AC-13: Ue: 250 VAC, Ie: 5 A DC-13: Ue: 30 VDC, Ie: 0.5 A Transistor Output: DC-13: Ue: 30 VDC, Ie: 0.1 A
Rated insulation voltage	250 V
Rated impulse withstand voltage (altitude: 2,000 m max.)	4 kV (at 240 VAC)
Conditional short-circuit current	1000 A

I/O Functions

For details, refer to the timing charts on page 20 and page 29.

	Start signal	Normally functions to start timing. In modes A-2 and A-3, disable timing. In mode S, starts and stops timing.	
Inputs *1 Reset the present value returns to the Count inputs are not accepted		 Resets present value. (In elapsed time mode, the present value returns to 0; in remaining time mode, the present value returns to the set value.) Count inputs are not accepted and control output turns OFF while reset input is ON. Reset indicator is lit while reset input is ON. 	
	Gate *2	Disables timing. (If a reset occurs while the gate input is ON, a reset will be performed.)	
Outputs	Control output (OUT)	Outputs take place according to designated operating mode when timer reaches corresponding set value.	

^{★1.} The H5CX-L8E does not have an input.

Response Delay Time When Resetting (Transistor Output)

The following table shows the delay from when the reset signal is input until the output is turned OFF. (Reference value)


Minimum reset signal width	Output delay time
1 ms	0.8 to 1.2 ms
20 ms	15 to 25 ms

^{*2.} The H5CX-L□ does not have a gate input.

H5CX-A□-N/-L□-N

Connections


Block Diagram



Note: Basic insulation is provided between the power supply circuit and the input circuits. However, basic insulation is not provided in the H5CX-\pip.N.

Terminal Arrangement

Confirm that the power supply meets specifications before use.



Power for load


connected to the H5CX.

Input Circuits

Signal, Reset, and Gate Input

No-voltage Inputs (NPN Inputs)

Voltage Inputs (PNP Inputs)






Input Connections

The inputs are no-voltage (closed or open) inputs or voltage inputs except for the H5CX-L8□. (The inputs of the H5CX-L8□ are no-voltage inputs only. The H5CX-L8E does not have an input.)


No-voltage Inputs (NPN Inputs)

Open Collector

PLC or input Signal input input 0 V for inputs Gate








Note: Operate with transistor ON


Voltage Output

Contact Input





DC Two-wire Sensor



Note: Operate with transistor ON

No-voltage Input Signal Levels

Note: Operate with transistor ON

No-contact	
input	

- Short-circuit level Transistor ON
- Residual voltage: 3 V max.
- Impedance when ON: 1 kΩ max.

(The leakage current is approx. 12 mA when the impedance is 0Ω .)

Open level Transistor OFF

• Impedance when OFF: 100 kΩ min.

Contact input Use contacts which can adequately switch 5 mA at 10 V

Note: The DC voltage must be 30 VDC max.

Applicable Two-wire Sensor

- Leakage current: 1.5 mA max.
- · Switching capacity: 5 mA min.
- Residual voltage: 3.0 VDC max.
- Operating voltage: 10 VDC


Voltage Inputs (PNP Inputs) The inputs of the H5CX-L8 are no-voltage inputs only.

No-contact Input (NPN Transistor)

Signal input Reset input 0 V for inputs H5CX-A□ 6 8


H5CX-A11□ 3 6 Note: Operate with transistor OFF

No-contact Input (PNP Transistor)



Note: Operate with transistor ON

Contact Input



Note: Operate with relay ON

Voltage Input Signal Levels

High level (Input ON): 4.5 to 30 VDC Low level (Input OFF): 0 to 2 VDC

The DC voltage must be 30 VDC max. Input resistance: Approx. 4.7 $k\Omega$

H5CX-A□-N/-L□-N

Nomenclature

Display Section

- 1. Key Protect Indicator (orange)
- 2. Control Output Indicator (orange)
- 3. Reset Indicator (orange)
- 4. Present Value Display (Main display) (Character height: 12 mm, red *) Characters on models with screw terminals (H5CX-A□) can be switched between red, green, and orange
- 5. Time Unit Indicators

(Color is same as present value display.) (If the time range is 0 min, 0 h, 0.0 h, or 0 h 0 min, these indicators flash to indicate timing operation.)

6. Set Value Display (Sub-display) (Character height: 6 mm, green)


7. Set Value 1, 2 Indicator (green)

Character Size for Present Value Display

Character Size for Set Value Display









Operation Key

8. Mode Key (Changes modes and setting items)

9. Reset Key

(Resets present value and output)

- 10. Up Keys 1 to 4
- 11. Down Keys 1 to 4

Switches

12. Key-protect Switch



13. DIP Switch



Note: There is no DIP switch on the H5CX-L8□.


(unit: mm)

Dimensions

Digital Timers


Digital Timers

H5CX-A-N/-AS-N (Flush Mounting Models)




Note: M3.5 terminal screw (effective length: 6 mm)

H5CX-AD-N/-ASD-N (Flush Mounting Models)




Note: M3.5 terminal screw (effective length: 6 mm)

H5CX-A11□-N (Flush Mounting/Surface Mounting Models)




H5CX-L8□-N (Flush Mounting/Surface Mounting Models)




Dimensions with Flush Mounting Adapter


H5CX-A-N/-AS-N (Provided with Adapter and Waterproof Packing)




H5CX-AD-N/-ASD-N (Provided with Adapter and Waterproof Packing)



H5CX-A11□-N (Adapter and Waterproof Packing Ordered Separately)




H5CX-L8□-N (Adapter and Waterproof Packing Ordered Separately)




Panel Cutouts

Panel cutouts areas shown below. (according to DIN43700).




Note: 1. The mounting panel thickness should be 1 to 5 mm.

- 2. To allow easier operation, it is recommended that Adapters be mounted so that the gap between sides with hooks is at least 15 mm (i.e., with the panel cutouts separated by at least 60 mm).
- 3. It is possible to horizontally mount Timers side by side. Attach the Flush Mounting Adapters so that the surfaces without hooks are on the sides of the Timers. (However, if Timers are mounted side by side, water resistance will be lost.)



 $A=(48n-2.5)^{+0}_{-0}^{+0}$ With Y92A-48F1 attached. $A=\{48n-2.5+(n-1)\times 4\}^{+0}_{-0}$ With Y92A-48 attached. $A=(51n-5.5)^{+0}_{-0}$

Dimensions with Front Connecting Socket



P2CF-11(-E) (order separately) Front Connecting Socket



P2CF-08(-E) (order separately) Front Connecting Socket

These dimensions vary with the type of DIN track (reference value).

Accessories (Order Separately)

Note:

Depending on the operating environment, the condition of resin products may deteriorate, and may shrink or become harder. Therefore, it is recommended that resin products are replaced regularly.

Front Panel (Replacement Part)


You can change the color of the front panel when mounting the Timer. The Timer is shipped with a black (N1.5) Front Panel.

Y92P-CXT4S

Cover for Timer with 4 Digits White (5Y9.2/0.5)

Y92P-CXT4G


Cover for Timer with 4 Digits



Y92P-CXT4B

Cover for Timer with 4 Digits Black (N1.5)

Replacement Method



The Front Panel is attached to the Terminal with tabs in four locations. To remove the Front Panel, open the tabs and pull the Front Panel forward.

To attach the Front Panel, press it onto the Timer so that all four tabs lodge into the groves on the body of the Timer.

Soft Cover Y92A-48F1



Hard Cover Y92A-48



Protecting the Timer in Environments Subject to Oil

The H5CX's panel surface is water-resistive (IP□6, UL Type 4X) and so even if drops of water penetrate the gaps between the keys, there will be no adverse effect on internal circuits. If, however, there is a possibility of oil being present on the operator's hands, use the Soft Cover. The Soft Cover ensures protection equivalent to IP54 against oil. Do not, however, use the H5CX in locations where it would come in direct contact with oil.

Waterproof Packing Y92S-29

Note: The Waterproof Packing is included with models with screw terminals.



Order the Waterproof Packing separately if it is lost or damaged. The Waterproof Packing can be used to achieve IP66 protection.

The Waterproof Packing will deteriorate, harden, and shrink depending on the application environment. To ensure maintaining the IP□6, UL Type 4X waterproof level, periodically replace the Waterproof Packing. The periodic replacement period will depend on the application environment. You must confirm the proper replacement period. Use 1 year or less as a guideline. If the Waterproof Packing is not replaced periodically, the waterproof level will not be maintained.

It is not necessary to mount the Waterproof Packing if waterproof construction is not required.

Flush Mounting Adapter Y92F-30 Y92F-45

Order the Flush Mounting Adapter separately if it is lost or damaged.

Note: A Flush Mounting Adapter is included with models with screw terminals.



Use this Adapter to install the Timer in a cutout previously made


for a DIN 72 x 72 mm device (panel cutout: 68 x 68 mm).




Y92F-38










- Insert timer unit from front side of adapter.
 Use Waterproof Packing to provide a level of water protection that complies with IP□6
- * It is not necessary to mount the Waterproof Packing if waterproof construction is not

Waterproof Packing Y92S-35






The Y92S-35 is not provided with Y92F-38. Order separately, if water protection is required. Use Waterproof Packing to provide a level of water protection that complies with IP65 standards.


Depending on the operating environment, the Waterproof Packing may deteriorate, contract, or harden and so regular replacement is recommended. The periodic replacement period will depend on the application environment. You must confirm the proper replacement period. Use 1 year or less as a guideline. If the Waterproof Packing is not replaced periodically, the waterproof level will not be maintained.

Connection Sockets Front-connecting Sockets



Note: Round crimp terminals cannot be used on Finger-safe Sockets. Use forked crimp terminals.


Back-connecting Sockets



Note: A Y92A-48G Terminal Cover can be used with the Socket to create a finger-safe construction.


H5CX-A□-N/-L□-N

Terminal Covers for P3G-08 and P3GA-11 Back-connecting Sockets



Note: The Terminal Cover can be used with a Back-mounting Socket (P3G-08 or P3GA-11) to create a finger-safe construction.

Optional Products for Track Mounting



Note: Order Spacers in increments of 10.

Operating Procedures

Setting Procedure Guide

Settings for Timer Operation *

Use the following settings.

Settings for Twin Timer Operation *

Refer to page 25.


* It is not necessary to mount the Waterproof Packing if waterproof construction is not required.

Operating Procedures for Timer Function



Settings for basic functions can be performed with just the DIP switch.

Note: There is no DIP switch on the H5CX-L8□. Go to Step2.



	Item	OFF	ON
1	DIP switch settings	Disabled	Enabled
2			
3	Time range	Refer to the table on the right.	
4			
5	Output modes	Refer to the table on	
6	Output modes	the ri	ght.
7	Timer mode	UP	DOWN
8	Input signal width	20 ms	1 ms

Note: All the pins are factory-set to OFF.

- Be sure to turn ON pin 1 of the DIP switch.
- Changes to DIP switch settings are enabled when the power is turned ON.


(Set the DIP switch while the power is OFF.)


Pin 2	Pin 3	Pin 4	Time range
ON	ON	ON	0.001 s to 9.999 s
OFF	OFF	OFF	0.01 s to 99.99 s
ON	OFF	OFF	0.1 s to 999.9 s
OFF	ON	OFF	1 s to 9999 s
ON	ON	OFF	0 min 01 s to 99 min 59 s
OFF	OFF	ON	0.1 min to 999.9 min
ON	OFF	ON	0 h 01 min to 99 h 59 min
OFF	ON	ON	0.1 h to 999.9 h

Pin 5	Pin 6	Output mode
OFF	OFF	Mode A: Signal ON delay 1 (Timer resets when power comes ON.)
ON	OFF	Mode A-2: Power ON delay 1 (Timer resets when power comes ON.)
OFF	ON	Mode E: Interval (Timer resets when power comes ON.)
ON	ON	Mode F: Cumulative (Timer does not reset when power comes ON.)
	OFF ON OFF	OFF OFF ON OFF OFF ON



After making DIP switch settings for basic operation, advanced functions can be added using the operation keys on the front panel. Refer to Step2 on page 16 for details.





H5CX-A□-N/-L□-N Timer

Explanation of Functions Operating Procedures for Timer Function

Items marked with stars (★) can be set using the DIP switch.

Time Range (ヒ೭̄ạ̄c)★

Set the range to be timed in the range 0.001 s to 9,999 h. Settings of type ---- h (9,999 h) and ---- min (9,999 min) cannot be made with the DIP switch. Use the operation keys if these settings are required.

Timer Mode (ヒ೭̄ạạ)★

Set either the elapsed time (UP) or remaining time (DOWN) mode. In UP mode, the elapsed time is displayed, and in DOWN mode, the remaining time is displayed.

Output Mode (Ճವರ್ಷ)★

Set the output mode.

The possible settings are A, A-1, A-2, A-3, b, b-1, d, E, F, Z and S. Only output modes A, A-2, E, and F can be set using the DIP switch. Use the operation keys if a different setting is required.

(For details on output mode operation, refer to "Timing Charts" on page 20.)

Output Time (atia)

When using one-shot output, set the output time for one-shot output (0.01 to 99.99 s).

One-shot output can be used only if the selected output mode is A, A-1, A-2, A-3, b, b-1 or S.

If the output time is set to 0.00, $\emph{H\"aL} d$ is displayed, and the output is held.

Input Signal Width (LFLE)★

Set the minimum signal input width (20 ms or 1 ms) for signal, reset, and gate inputs.

The same setting is used for all external inputs (signal, reset, and gate inputs).

If contacts are used for the input signal, set the input signal width to 20 ms.

Processing to eliminate chattering is performed for this setting.

NPN/PNP Input Mode (Land)

Select either NPN input (no-voltage input) or PNP input (voltage input) as the input format.

Set an NPN input when using a 2-wire sensor.

For details on input connections, refer to "Input Connections" on page 9.

Display Color (Lalr)

(Terminal block model: H5CX-A□ only)

Set the color used for the present value.

	Output OFF	Output ON	
rEd	Red (fixed)	
Gra	Green	(fixed)	
۵rű	Orange	e (fixed)	
r-G	Red	Green	
G-r	Green	Red	
r-ŏ	Red Orange		
ŏ-r	Orange	Red	
ű-ő	Green	Orange	
ă-G	Orange	Green	

Key Protect Level (# 남부분)

Set the key protect level.

Refer to "Key Protect Level" on page 32.

Instantaneous/Time-limit (るとのは)

Set the contact output to time-limit SPDT + instantaneous SPDT or time-limit SPDT operation.

Set Value Upper Limit (5L -H)

Set the upper limit for the set value when it is set in Run Mode.

The limit can be set to between 1 and 9999.

This setting does not apply to the ON duty in Z mode.

Output ON Count Alarm Set Value (an-A)

Set the alarm value for the output ON count.

The limit can be set to between $\underline{0}$ x 1000 (0 times) and $\underline{9999}$ x 1000 (9,999,000 times). Only the underlined values are set. The alarm will be disabled if 0 is set.

If the total ON count of the output exceeds the alarm set value, $\mathcal{E}3$ will be displayed on the Timer to indicate that the output ON count alarm value was exceeded. Refer to "Self-diagnostic Function" on page 32 for information on the $\mathcal{E}3$ display.

ON Count Alarm Set Values for Outputs 1 and 2 (OUT1 and OUT2) (อัก เหิ and อักะิหิ)

Set the ON count alarm values for the outputs 1 and 2.

The limit can be set to between $\underline{0}$ x 1000 (0 times) and $\underline{9999}$ x 1000 (9,999,000 times). Only the underlined values are set. The alarm will be disabled if 0 is set.

If the total ON count of instantaneous output 1 or 2 exceeds the alarm set value, £3 will be displayed on the Timer to indicate that the output ON count alarm value was exceeded. Refer to "Self-diagnostic Function" on page 32 for information on the £3 display.


Output ON Count Monitor Value (an-L)

The monitor value is only displayed. It cannot be set. The output ON count will be 1,000 times the displayed value.

ON Count Monitor Values for Outputs 1 and 2 (OUT1 and OUT2) (an IE and an EE)

The monitor value for output 1 or 2 is only displayed. It cannot be set. The output ON count will be 1,000 times the displayed value.

Operation in Run Mode Operating Procedures for Timer Function



Present Value and Set Value

These items are displayed when the power is turned ON. The present value is displayed in the main display and the set value is displayed in the sub-display.

The values displayed will be determined by the settings made for the time range and the timer mode in function setting mode.

Present Value and ON Duty Ratio (Output Mode = Z)

The present value is displayed in the main display and the ON duty ratio is displayed in the sub-display. Set the ON duty ratio used in ON/ OFF-duty-adjustable flicker mode (Z) as a percentage.

The output accuracy will vary with the time range, even if the ON duty ratio setting is the same. Therefore, if fine output time adjustment is required, it is recommended that the time range for the cycle time is set as small as possible.

Examples: 1. When Time Range = - - - s (9999 s)

$$20(s) \times \frac{31(\%)}{100} = 6.2(s)$$

Rounded off to the nearest integer (because of the time range setting) \rightarrow ON time = 6 s

2. When Time Range = - -. - s (99.99 s)


$$20.00(s) \times \frac{31(\%)}{100} = 6.200(s)$$

Rounded off to 2 decimal places (because of the time range setting) \rightarrow ON time = 6.20 s

If a cycle time is set, cyclic control can be performed in ON/OFF-duty-adjustable flicker mode simply by changing the ON duty ratio.

Present Value and Cycle Time (Output Mode = Z)

The present value is displayed in the main display and the cycle time is displayed in the sub-display. Set the cycle time.




Timing Charts

Operating Procedures for Timer Function

Models without Instantaneous Contact Outputs

The gate input is not included in the H5CX-L8□ models.


Either one-shot output or sustained output can be selected.



*Start signal input is disabled during timing.

Timing starts when the start signal goes ON. While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF. The control output is controlled using a sustained or one-shot time period.

Note: Output is instantaneous when setting is 0.



Mode A-1: Signal ON delay 2 (Timer resets when power comes ON.)


Basic operation





Timing starts when the start signal goes ON, and resets when the start signal goes OFF. While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF. The control output is controlled using a sustained or one-shot time period.

Note: Output is instantaneous when setting is 0.



Mode A-2: Power ON delay 1 (Timer resets when power comes ON.)

Basic operation


Detailed operation



Timing starts when the reset input goes OFF. The start signal disables the timing function (i.e., same function as the gate input).


The control output is controlled using a sustained or one-shot time period.

Note: Output is instantaneous when setting is 0.



Mode A-3: Power ON delay 2 (Timer does not reset when power comes ON.)


Basic operation



Timing starts when the reset input goes OFF. The start signal disables the timing function (i.e., same function as the gate input).

The control output is controlled using a sustained or one-shot time period.

Note: Output is instantaneous when setting is 0.



Mode b: Repeat cycle 1 (Timer resets when power comes ON.)

Basic operation

input Timing ---- Timing Output


*Start signal input is disabled during timing.

Timing starts when the start signal goes ON. The status of the control output is reversed when time is up (OFF at start).

While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF.

Note: Normal output operation will not be possible if the set time is too short

Set the value to at least 100 ms (contact output type).




*Start signal input is disabled during timing.

Timing starts when the start signal goes ON. The control output is turned ON when time is up. While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF.


Note: Normal output operation will not be possible if the set time is too short.

Set the value to at least 100 ms (contact output type).

Detailed operation







Mode b-1: Repeat cycle 2 (Timer does not reset when power comes ON.)

Basic operation

Start signal

input Output


*Start signal input is disabled during timing.

TimingTimin

Timing starts when the start signal goes ON. The status of the control output is reversed when time is up (OFF at start).

While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF. Note: Normal output operation will not be possible if

the set time is too short. Set the value to at least 100 ms (contact output type).



*Start signal input is disabled during timing.


Timing starts when the start signal goes ON. The control output is turned ON when time is up. While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF.

Note: Normal output operation will not be possible if the set time is too short.


Set the value to at least 100 ms (contact output type).

Detailed operation


Sustained Output




One-shot Output



H5CX-A□-N/-L□-N Timer






*Start signal input is enabled during timing.


The control output is ON when the start signal is ON (except when the power is OFF or the reset is ON). The timer resets when the time is up.

Note: Output functions only during start signal input when setting is 0.



Mode E: Interval (Timer resets when power comes ON.)


Basic operation Detailed operation



*Start signal input is enabled during timing.


Timing starts when the start signal comes ON. The timer resets when the time is up. While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF.

Note: Output is disabled when the setting is 0.



Mode F: Cumulative (Timer does not reset when power comes ON.)


Basic operation Detailed operation



Start signal enables timing (timing is stopped when the start signal is OFF or when the power is OFF). A sustained control output is used.


Note: Output is instantaneous when setting is 0.

When the H5CX is used with power start, there will be a timer error (approximately 100 ms each time the H5CX is turned ON) due to the characteristics of the internal circuitry. Use the H5CX with signal start if timer accuracy is required.



Mode Z: ON/OFF-duty-adjustable flicker (Timer resets when power comes ON.)

Basic operation Detailed operation





*Start signal input is disabled during timing.

Timing starts when the start signal goes ON.
The status of the control output is reversed when time is up (ON at start).

While the start signal is ON, the timer starts when power comes ON or when the reset input goes OFF.

Note: Normal output operation will not be possible if the set time is too short.
Set the value to at least 100 ms (contact output type).





Time-limit

Time-limit

contacts, NC One-shot Output Time-limit contacts, NO

> contacts, NC Instantaneous contacts, NO

contacts, NO

Note: H5CX-L8E□-N Precautions

the reset input goes OFF.


Note: Normal output operation will not be possible if

the set time is too short. Set the value to at least 100 ms.

Set the Timer's set value before using the Timer in a self-holding circuit.


t = Set time, Rt = Reset time (0.5 s min.), t – a < t (Indicates the time is less than the set time.)

H5CX-A□-N/-L□-N **Timer**



Note: H5CX-L8E□-N Precautions
Set the Timer's set value before using the Timer in a self-holding circuit.

Setting Procedure Guide Operating Procedures for Twin Timer Function



OFF

ON

OFF

OFF

	Item	OFF	ON	
1	DIP switch settings	Disabled	Enabled	
2	OFF time range	Refer to the tak	ole on the right	
3	Of Fullie lange	Refer to the table on the right.		
4	ON time range	Defeate the table on the sinkt		
5	ON time range	Refer to the table on the right.		
6	Output mode	Flicker OFF start	Flicker ON start	
7	Timer mode	UP	DOWN	
8	Input signal width 20 ms 1 ms			
Note: All the mine are factors and to OFF				

Pin /	Din 5	ON time range
ON	ON	0 min 01 s to 99 min 59 s
OFF	ON	1 s to 9999 s
0.1	011	0.1 0 10 000.0 0

0.01 s to 99.99 s

0.1 s to 999.9 s

Note: All the pins are factory-set to OFF.

	Pin 4	Pin 5	ON time range
•	OFF	OFF	0.01 s to 99.99 s
	ON	OFF	0.1 s to 999.9 s
	OFF	ON	1 s to 9999 s
	ON	ON	0 min 01 s to 99 min 59 s


- Be sure to turn ON pin 1 on the DIP switch.
- Changes to DIP switch settings are enabled when the power is turned ON.
 (Perform DIP switch settings while the power is OFF.)




After making DIP switch settings for basic operation, advanced functions can be added using the operation keys on the front panel. Refer to Step3 on page 26 for details.

H5CX-A□-N/-L□-N Twin Timer

To switch to twin timer operation, use the procedure given below. For details, refer to page 31.





Explanation of Functions

Operating Procedures for Twin Timer Function

Items marked with stars (★) can be set using the DIP switch.

OFF Time Range (oFtr)★

Set the time range for the OFF time in the range $0.000 \, s$ to $9,999 \, h$. Only settings of type --.-- s $(99.99 \, s)$, ---- s $(999.9 \, s)$, ---- s $(99.99 \, s)$, and -- min -- s $(99 \, min \, 59 \, s)$ can be made with the DIP switch. Use the operation keys if another type of setting is required.

ON Time Range (ōnkr)★

Set the time range for the ON time in the range 0.001 s to 9,999 h. Only settings of type --.-- s (99.99 s), ---- s (999.9 s), ---- s (999.9 s), and -- min -- s (99 min 59 s) can be made with the DIP switch. Use the operation keys if another type of setting is required.

Timer Mode (ピムạạ)★

Set either the elapsed time (UP) or remaining time (DOWN) mode. In UP mode, the elapsed time is displayed, and in DOWN mode, the remaining time is displayed.

ON/OFF Start Mode (₺፩₺雨)★

Set the output mode.

Set either flicker OFF start or flicker ON start. (For details on output mode operation, refer to "Timing Charts" on page 29.)

Input Signal Width (LFLE)★

Set the minimum signal input width (20 ms or 1 ms) for signal, reset, and gate inputs.

The same setting is used for all external inputs (signal, reset, and gate inputs).

If contacts are used for the input signal, set the input signal width to 20 ms.

Processing to eliminate chattering is performed for this setting.

NPN/PNP Input Mode ([mod)

Select either NPN input (no-voltage input) or PNP input (voltage input) as the input format. Set an NPN input when using a 2-wire sensor. The same setting is used for all external inputs.

For details on input connections, refer to "Input Connections" on page 9.

Display Color (LaLr)

(Terminal black model: H5CX-A□ only)

Set the color used for the present value.

	Output OFF	Output ON
rEd	Red (fixed)
Gra	Green	(fixed)
۵r۵	Orange	e (fixed)
r-G	Red	Green
<u> 5</u>	Green	Red
r-ō	Red	Orange
ŏ-r	Orange	Red
ű-ő	Green	Orange
ŏ-G	Orange	Green


Key Protect Level (# 남부분)

Set the key protect level.

Refer to "Key Protect Level" on page 32.

Operation in Run Mode

Operating Procedures for Twin Timer Function



Note: 1. The display will automatically show the OFF set time when the OFF time is being timed and the ON set time when the ON time is being timed.

Note: 2. H5CX-L8E□-N Precautions

Set the Timer's set value before using the Timer in a self-holding circuit.

Present Value and OFF Set Time

The present value is displayed in the main display and the OFF set time is displayed in the sub-display. Set the OFF time.

Present Value and ON Set Time

The present value is displayed in the main display and the ON set time is displayed in the sub-display. Set the ON time.

Timing Charts


Operating Procedures for Twin Timer Function

Models without Instantaneous Contact Outputs

The gate input is not included in the H5CX-L8□ models.

Mode toff: Flicker OFF start 1 (Timer resets when power comes ON.)

Basic operation




*Start signal input is disabled during timing.

Timing starts when the start signal goes ON. The status of the control output is reversed when time is up (OFF at start).


While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF.

Note: Normal output operation will not be possible if the set time is too short.
Set the value to at least 100 ms (contact output



Mode ton: Flicker OFF start 1 (Timer resets when power comes ON.)

Basic operation




*Start signal input is disabled during timing.

Timing starts when the start signal goes ON. The status of the control output is reversed when time is up (ON at start).

While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF.


Note: Normal output operation will not be possible if the set time is too short.

Set the value to at least 100 ms (contact output type).



Mode toff-1: Flicker OFF start 2 (Timer does not reset when power comes ON.)

Basic operation




*Start signal input is disabled during timing.


Timing starts when the start signal goes ON. The status of the control output is reversed when time is up (OFF at start).

While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF.


Note: Normal output operation will not be possible if the set time is too short.
Set the value to at least 100 ms (contact output



H5CX-A□-N/-L□-N Twin Timer



(a + b = OFF time)



*Start signal input is disabled during timing.


Output

Timing starts when the start signal goes ON. The status of the control output is reversed when time is

up (ON at start). While the start signal is ON, the timer starts when the

power comes ON or when the reset input goes OFF. Note: Normal output operation will not be possible if the set time is too short.

Set the value to at least 100 ms (contact output type).




Models with Instantaneous Contact Outputs

Mode toff: Flicker OFF start 1 (Timer resets when power comes ON.) **Basic operation Detailed operation** Toff time Ton time Toff time

Time-limit Instantaneous


The Timer starts when the power comes ON or when the reset input goes OFF.

Note: Normal output operation will not be possible if the set time is too short. Set the ON time and OFF time to at least 100




t-on = ON time, t-off = OFF time, Rt = Reset time (0.1 s min.), t – a < t-off and t – b < t-on (Indicates the time is less than the set time.)

Mode ton: Flicker ON start 1 (Timer resets when power comes ON.)



The Timer starts when the power comes ON or when the reset input goes OFF

Note: Normal output operation will not be possible if the set time is too short.
Set the ON time and OFF time to at least 100




H5CX-L8E□-N Precautions Note:

Set the Timer's set value before using the Timer in a self-holding circuit.

Timer/Twin Timer Selection Mode (Function Selection)

Select whether the H5CX is used as a timer or a twin timer in timer/twin timer selection mode.

The H5CX is also equipped with a DIP switch monitor function, a convenient function that enables the settings of the DIP switch pins to be confirmed using the front display.





Caution

To change the mode to timer/twin timer selection mode, hold down the <a>1 key for 1 s min. with the <a>0 key held down. The <a>1 key must be pressed before the key. If the key is pressed first, the mode will not change.


Select either <code>Lim</code> timer operation or <code>Lum</code> twin timer operation using the

Note: The H5CX is factory-set for timer operation.

Confirm the status of DIP switch pins 1 to 8 using the 🕱 😸 keys.

Note: 1. This display is not supported with H5CX-L8□-N.

This display is only possible when DIP switch pin 1 (DIP switch settings enable/disable) is set to ON (enable).




- *1. When the mode is changed to timer/twin timer selection mode, the present value is reset and output turns OFF. Timing operation is not performed in timer/twin timer selection mode.
- *2. Setting changes made in timer/twin timer selection mode are enabled when the mode is changed to run mode. If settings are changed, the HC5X is automatically reset (present value initialized, output turned OFF).

Key Protect Level

When the key-protect switch is set to ON, it is possible to prevent setting errors by prohibiting the use of certain operation keys by specifying the key protect level (KP-1 to KP-7).

The key protect indicator is lit while the key-protect switch is set to ON.



		Details				
Level	Meaning	Changing mode*	Switching display during operation	Reset Key	Up/down key	
KP-1 (default setting)	MODE 4 5 7 7 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Invalid	Valid	Valid	Valid	
KP-2	MODE 4 3 7 7 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Invalid	Valid	Invalid	Valid	
KP-3	MODE 4 Omnon H5CX	Invalid	Valid	Valid	Invalid	
KP-4	MODE 4 ORROW H5CX	Invalid	Valid	Invalid	Invalid	
KP-5	MODE OF THE STATE	Invalid	Invalid	Invalid	Invalid	
KP-6	MODE A STATE OF THE STATE OF TH	Invalid	Invalid	Valid	Valid	
KP-7	MODE OTRINON H5CX	Invalid	Invalid	Invalid	Valid	

^{*} Changing mode to Timer/Twin Timer Selection Mode or Function Setting Mode.

Self-diagnostic Function

The following displays will appear if an error occurs.

Main display	Sub-display	Error	Output status	Correction method	Set value after reset
E !	Not lit	CPU	OFF	Either press the reset key or reset the power supply.	No change
53	Not lit	Memory error (RAM)	OFF	Reset the power supply.	No change
53	5Un	Memory error EEPROM *1	OFF	Reset Key	Factory setting
E3 *2	No change	Output ON count alarm set value exceeded	No change	Reset Key	No change

^{*1.} This includes times when the life of the EEPROM has expired.

^{*2.} The normal display and £3 will appear alternately.

When the Reset Key is pressed, £3 will no longer be displayed even if the alarm set value is exceeded. (Monitoring is possible, however, because the Timer will continue without clearing the output ON count.)

Digital Timer H5CX-BWSD-N

- H5CX Digital Timers with 6-digit Display, 2-stage Setting, and Forecast Output (DIN 48 x 48-mm)
- Times the daily operating hours of machinery and tools, predicting and notifying when maintenance is required.
- Easy-to-read backlit negative LCD with 6 digits (displays to 99999.9 h).
- The 2-stage settings and forecast output are ideal for maintenance applications.





For the most recent information on models that have been certified for safety standards, refer to your OMRON website.

Specifications

Ratings

	,•			
Classificat	ion	Digital Timer with 6-digit display, 2-stage setting, and forecast output		
	Power supply voltage	12 to 24 VDC		
Ratings	Operating voltage fluctuation range	90% to 110% rated supply voltage		
	Power consumption	Approx. 2.3 W *1		
Mounting I	method	Flush mounting		
External co	onnections	Screw terminals		
Degree of	Degree of protection IEC IP66, UL508 Type 4X (indoors) for panel front surface only and only when Y92S-29 Waterproof Packing is us			
Digits		6 digits		
Time range	9	0.01 s to 9999.99 s, 1 s to 99 h 59 min 59 s, 0.1 min to 99999.9 min, 0.1 h to 99999.9 h		
Timer mod	le	Elapsed time (Up)		
	Input signals	Signal, reset, gate		
Inputs	Input method			
	Signal, reset, gate	Minimum input signal width: 1 or 20 ms (selectable, same for all input)		
Reset syst	Power resets (only for A mode), external and manual reset			
Power rese	et	Minimum power-opening time: 0.5 s (except for F-1 mode)		
Reset volta	age	10% max. of rated supply voltage		
Sensor wa	iting time	250 ms max. (Control output is turned OFF and no input is accepted during sensor waiting time.)		
	Output modes	A, F-1		
Outputs	Output type	Transistor output: NPN open collector, 100 mA at 30 VDC max. residual voltage: 1.5 VDC max. (Approx. 1 V) Leakage current: 0.1 mA max.		
Display	7-segment, negative transmissive LCD; Present value: 10-mm-high characters, red Set value: 6-mm-high characters, green *2			
Memory backup EEPROM (overwrites: 100,000 times min.) that can store data for 10 years min.		EEPROM (overwrites: 100,000 times min.) that can store data for 10 years min.		
Operating temperature range -10 to 55°C (-10 to 50°C if counters are mounted side by side) (with no icing or condensation)		-10 to 55°C (-10 to 50°C if counters are mounted side by side) (with no icing or condensation)		
Storage te	mperature range	-25 to 70°C (with no icing or condensation)		
Operating	humidity range	25 to 85%		
Case color		Black (N1.5)		
Attachmer	nts	Waterproof packing, flush mounting adapter, unit label		

***1.** Inrush current will flow for a short time when the power supply is turned ON. Inrush Current (Reference Values)

Voltage	Applied voltage	Inrush current (peak value)	Time
12 to 24 VDC	26.4 VDC	4.4 A	1.7 ms

***2.** The display is lit only when the power is ON.

Characteristics

Accuracy of operating time and setting error (including temperature and voltage influences)		Power-ON start: ±0.01% ±50 ms max. (See note 1.) Signal start: ±0.005%±0.03 ms max. (See note 1.) Signal start for transistor output model: ±0.005%±3 ms max. (See note 1 and 2.) If the set value is within the sensor waiting time at startup the control output of the H5CX will not turn ON until the sensor waiting time passes. Note: 1. The values are based on the set value. 2. The value is applied for a minimum pulse width of 1 ms.	
Insulation resis	tance	100 MΩmin. (at 500 VDC) between current-carrying terminal and exposed non-current-carrying metal parts	
Dielectric stren	gth	2,000 VAC, 50/60 Hz for 1 min between current-carrying metal parts and non-current-carrying metal parts 1,000 VAC, 50/60 Hz for 1 min between control output, power supply, and input circuit	
Impulse withstand voltage		1.0 kV (between power terminals) 1.5 kV (between current-carrying terminal and exposed non-current-carrying metal parts)	
Noise immunity		±480 V (between power terminals) and ±600 V (between input terminals), square-wave noise by noise simulator (pulse width: 100 ns/1 μs, 1-ns rise)	
Static immunity	1	Destruction: 15 kV Malfunction: 8 kV	
Vibration	Destruction	10 to 55 Hz with 0.75-mm single amplitude in three directions for 2 h each	
resistance	Malfunction	10 to 55 Hz with 0.35-mm single amplitude in three directions for 10 min each	
Shock	Destruction	300 m/s² in three directions, three cycles	
resistance	Malfunction	100m/s ² in three directions, three cycles	
Weight		Approx. 105 g (Timer only)	

Applicable Standards

Approved safety standards	UL508/Listing, CSA C22.2 No. 14, conforms to EN 61812-1 (pollution degree 2/overvoltage category III) Conforms to VDE0106/P100 (finger protection).		
EMC	(EMI) Emission Enclosure: (EMS) Immunity ESD: Immunity Burst: Immunity Surge: Immunity Conducted Disturbance: Immunity Voltage Dip/Interruption:	EN61812-1 EN55011 Group 1 class A EN61812-1 IEC61000-4-2 IEC61000-4-3 IEC61000-4-4 IEC61000-4-5 IEC61000-4-6 IEC61000-4-11	

I/O Functions

Inputs	Start signal		Starts timing.		
			 Resets present value. (The present value returns to 0.) Timing stops and control output turns OFF while reset input is ON. Reset indicator is lit while reset input is ON. 		
	Gate		Inhibits timer operation.		
	i diddadi valud	Control output (OUT2)	Turns ON when the present value reaches the set value.		
Outputs		Forecast output (OUT1)	Turns ON when the present value reaches the forecast value.		
	Absolute value	Control output 2 (OUT2)	Turns ON when the present value reaches set value 2.		
		Control output 1 (OUT1)	Turns ON when the present value reaches set value 1.		

Response Delay Time When Resetting (Transistor Output)


The following table shows the delay from when the reset signal is input until the output is turned OFF.

(Reference value)


Minimum reset signal width	Output delay time		
1 ms	0.8 to 1.2 ms		
20 ms	15 to 25 ms		

Connections

Block Diagram



Terminal Arrangement




- **Note: 1.** The power supply and input circuit are not isolated.
 - Terminals 1 and 6 are connected 2. internally.
 - Terminals 7 and 10 have the same reset function. The same function will be performed whichever terminal is connected. Terminals 7 and 10 are not connected internally, however, so do not use them for cross-over wiring.

Input Circuits

Signal, Reset, and Gate Input


No-voltage Inputs (NPN Inputs) Voltage Inputs (PNP Inputs)





Transistor Output

- · The transistor output of the H5CX is insulated from the internal circuitry by a photocoupler, so the transistor output can be used as both NPN and PNP output.
- The diode connected to the collector of the output transistor is used to absorb inverted voltage that is generated when an inductive load is connected to the H5CX.




Power for load

Input Connections

The inputs of the H5CX-B are no-voltage (short-circuit or open) inputs or voltage inputs.

No-voltage Inputs (NPN Inputs)


Open Collector




Note: Operate with transistor ON

7 8


Voltage Output



Contact Input



DC Two-wire Sensor



No-voltage Input Signal Levels


No-contact input	Short-circuit level (Transistor ON) • Residual voltage: 3 V max. • Impedance when ON: 1 $k\Omega$ max. (The leakage current is approx. 12 mA when the impedance is 0 Ω .)
	Open level (Transistor OFF) • Impedance when OFF: 100 kΩ min.
Contact input	Use contacts which can adequately switch 5 mA at 10 V

Applicable Two-wire Sensor Leakage current: 1.5 mA max. Switching capacity: 5 mA min. Residual voltage: 3.0 VDC max.

Operating voltage: 10 VDC

Voltage Inputs (PNP Inputs)

No-contact Input (NPN Transistor)




Note: Operate with transistor OFF **Voltage Input Signal Levels**

High level (Input ON): 4.5 to 30 VDC Low level (Input OFF): 0 to 2 VDC


The DC voltage must be 30 VDC max. Input resistance: Approx. 4.7 $k\Omega$

No-contact Input (PNP Transistor)



Note: Operate with transistor ON

Contact Input



Note: Operate with relay ON

H5CX-BWSD-N

Nomenclature

Display Section

1. Key Protection Indicator (orange) Lit when the reset input or Reset Key is ON.

2. Control Output Indicator (orange)

Forecast value setting
Forecast output ON: OUT 1 is lit. Control output ON: OUT 2 is lit. Absolute value setting Control output 1 ON: OUT 1 is lit. Control output 2 ON: OUT 2 is lit.

3. Reset Indicator (orange)

Lit when the reset input or Reset Key is ON.

4. Present Value Display (red)

Character height: 10 mm If the time range is 0.0 min or 0.0 h, the decimal point flashes to indicate timing operation.

5. Time Unit Indicators (green)

6. Set Value (green) Character height: 6 mm


7. Set Value 1, 2 Indicator (green)



Character Size for Set Value Display



TIMER 2 8 Sixth digit First digit



Operation Key

8. Mode Key

(Changes modes and setting items)

Reset Key

Resets present value and output.

10. Up Keys 1 to 6

Switches

11. Key-protect Switch



12. DIP Switch



Key Protect Level

When the Key-protect Switch is ON, key operations are prohibited according to the settings for DIP switch pins 6 to 8, thus preventing

The Key-protect Switch can be turned ON and OFF while the power is ON.

The Key Protection Indicator is lit orange when the Key-protect Switch is ON.

If the key protect switch is ON, you will not be able to switch to Function Setting Mode.

Dimensions (unit: mm)


Digital Timers

Digital Timers

H5CX-BWSD-N (Flush Mounting Models)








Note: M3.5 terminal screw (effective length: 6 mm)


Panel Cutouts

Panel cutouts areas shown below. (according to DIN43700)



Note: 1.


- The mounting panel thickness should be 1 to 5 mm.
 To allow easier operation, it is recommended that Adapters be mounted so that the gap between sides with hooks is at least 15 mm (i.e., with the panel cutouts separated by at least 60 mm). It is possible to mount Timers side by
- side, but only in the direction without the hooks. However, if Timers are mounted side by side, water resistance will be lost.



With Y92A-48F1 attached. $A=\{48n-2.5+(n-1)\times 4\}_{-1}^{+1}$ With Y92A-48 attached. $A = (51n - 5.5)^{+1}_{-0}$

Dimensions with Flush Mounting Adapter H5CX-BWSD-N (Provided with Adapter and Waterproof Packing)





Accessories (Order Separately)

Refer to page 12 for details.


Operating Procedures

DIP Switch Settings

All functions are set using the DIP switch.

	Item	OFF	ON		
1	Time range	Refer to the table on the			
2		right.			
3	Output modes	F-1 mode	A mode		
4	Input signal width	20 ms	1 ms		
5	NPN/PNP input mode	NPN (no-voltage)	PNP (voltage)		
6	Reset Key protection	Disabled	Enabled		
7	Up Key protection	Disabled	Enabled		
8	Mode Key protection	Disabled	Enabled		

	Pin 1	Pin 2	Time range				
•	OFF	OFF	0.1 h to 99999.9 h				
	ON	OFF	0.01 s to 9999.99 s				
	OFF	ON	0 h 00 min 01 s to 99 h 59 min 59 s				
	ON	ON	0.1 min to 99999.9 min				




Note: 1. All the pins are factory-set to OFF.

DIP switch settings are effective when the power is turned ON again. (Set the DIP switch before installation and power-up.)


Operation in Run Mode

Set the digits for the set values using the corresponding (Key.

Forecast Value Setting



Absolute Value Setting





Each time the MODE Key is pressed, the sub-display will switch between set value 1 ("SET 1" is lit) and set value 2 ("SET 2" is lit).

Operation in Function Setting Mode

Settings that cannot be performed with the DIP switch are performed with the operation keys.

• Change to Function Setting Mode.






Explanation of Functions

Absolute value setting/forecast value setting (SEŁm)

Set value 1 can be set as the forecast value setting (5F5E) or the absolute value setting (865).


Forecast Value Setting



- OUT1 (forecast output) turns ON when the present value reaches the forecast value.

 Forecast value = Set value - Forecast set value
- Note: The forecast set value is used to set the deviation for the set value.
- OUT2 (control output) turns ON when the present value reaches the set value.
- If the forecast set value ≥ set value, OUT1 (forecast output) will turn ON as soon as timing starts.

Absolute Value Setting



- OUT1 (control output 1) turns ON when the present value reaches set valùe 1.
- OUT2 (control output 2) turns ON when the present value reaches set value 2.

Refer to pages 18 and 28 for information on other functions.

Self-diagnostic Function

The following displays will appear if an error occurs.

Main display	Sub-display	Error	Output status	Correction method	Set value after reset
E !	E! Not lit CPU		OFF Either press the Reset Ke reset the power supply.		No change
£2	Not lit	Memory error (RAM)	OFF	Reset the power supply.	No change
E2	SUm	Memory error EEPROM *1	OFF	Reset Key.	Factory setting
£ 3 *2	No change	Output ON count alarm set value exceeded	No change	Reset Key	No change

- ***1.** This includes times when the life of the EEPROM has expired.

***2.** The normal display and £ 3 will appear alternately.

When the Reset Key is pressed, £ 3 will no longer be displayed even if the alarm set value is exceeded. (Monitoring is possible, however, because the Timer will continue without clearing the output ON count.)


Timing Charts

Mode A: Signal ON delay (Timer resets when power comes ON.)

Basic operation Start signal input Forecast output OUT1 output OUT1 Control output 2 output 2 OUT2 OUT2 () The names in parentheses are used for the absolute value setting. Control

- *Start signal input is disabled during timing.
- Timing starts when the start signal goes ON.
- While the start signal is ON, the timer starts when the power comes ON or when the reset input goes OFF.
- A sustained control output is used.
- Timing stops when the time is up.


Note: Output is instantaneous when the set value is 0.



Mode F-1: Cumulative (Timer does not reset when power comes ON.)

Basic operation


Detailed operation



- Start signal enables timing (timing is stopped when the start signal is OFF or when the power is OFF).
- A sustained control output is used.
- Timing continues even after the time is up.

Note: Output is instantaneous when the set value is

When the $\mbox{H5CX}$ is used with power start, there will be a timer error (approximately 100 ms each time the H5CX is turned ON) due to the characteristics of the internal circuitry. Use the H5CX with signal start if timer accuracy is required.



The names in parentheses are used for the absolute value setting.

The forecast value = set value - forecast set value

The forecast set value is used to set the deviation for the set value.

Safety Precautions for All H5CX Series (Common)

⚠ CAUTION

Do not allow pieces of metal, wire clippings, or fine metallic shavings or fillings from installation to enter the product. Doing so may occasionally result in electric shock, fire, or malfunction.



Minor injury due to explosion may occasionally occur. Do not use the Timer where subject to flammable or explosive gas.



Fire may occasionally occur. Tighten the terminal screws to the rated torque.



H5CX terminals: 6.55 to 7.97 lb-in (0.74 to 0.90 N⋅m) P2CF Socket terminals: 4.4 lb-in (0.5 N⋅m)

Minor injury due to electric shock may occasionally occur. Do not touch any of the terminals while power is being supplied. Be sure to mount the terminal cover after wiring.




The life expectancy of the output relay varies considerably according to its usage. Use the output relay within its rated load and electrical life expectancy. If the output relay is used beyond its life expectancy, its contacts may become fused or there may be a risk of fire. Also, be sure that the load current does not exceed the rated load current and when using a heater, be sure to use a thermal switch in the load circuit.

Minor electric shock, fire, or malfunction may occasionally occur. Do not disassemble, modify, or repair the Timer or touch internal components.




Precautions for Safe Use

 The panel surface of the H5CX is water-resistant (conforming to NEMA4, IP66, UL Type 4X (Indoor Use Only). To protect the internal circuits from water penetration through the space between the H5CX and operating panel, waterproof packing is available as an accessory. Attach the Y92F-30 Adapter with sufficient pressure with the reinforcing screws so that water does not penetrate the panel.



- When mounting the Timer to a panel, tighten the two mounting screws alternately, a little at a time, so as to keep them at an equal tightness. If the panel screws are tightened unequally, water may enter the panel.
- Store the Timer at the specified temperature. If the Time has been stored at a temperature of less than -10°C, allow the Time to stand at room temperature for at least 3 hours before use.
- Mounting the Timer side-by-side may reduce the life expectancies of internal components.
- Use the Timer within the specified ranges for the ambient operating temperature and humidity.
- Do not use in the following locations:
 - Locations subject to sudden or extreme changes in temperature.
 - Locations where high humidity may result in condensation.
- Do not use the Timer outside of the rated ranges for vibration, shock, water exposure, and oil exposure.
- Do not use this Timer in dusty environments, in locations where corrosive gasses are present, or in locations subject to direct sunlight.
- Install the Timer well away from any sources of static electricity, such as pipes transporting molding materials, powders, or liquids.
- Internal elements may be destroyed if a voltage outside the rated voltage range is applied.

- Be sure that polarity is correct when wiring the terminals.
- Separate the Timer from sources of noise, such as devices with input signals from power lines carrying noise, and wiring for I/O signals.
- Do not connect more than two crimp terminals to the same terminal.
- Up to two wires of the same size and type can be inserted into a single terminals.
- Use the specified wires for wiring.
 Applicable Wires: AWG 18 to AWG 22, solid or twisted, copper.
 Wiring stripping length: 5 to 6 mm (recommended)
- Install a switch or circuit breaker that allows the operator to immediately turn OFF the power, and label it to clearly indicate its function.
- When the Timer is operated with no-voltage input (NPN input), approximately 14 V is output from the input terminals. Use a sensor that contains a diode.



- Use a switch, relay, or other contact so that the rated power supply voltage will be reached within 0.1 seconds. If the power supply voltage is not reached quickly enough, the Timer may malfunction or outputs may be unstable.
- Use a switch, relay, or other contact to turn the power supply OFF instantaneously. Outputs may malfunction and memory errors may occur if the power supply voltage is decreased gradually.
- H5CX-A□-N/-L□-N:

When changing the set value during a timing operation, the output will turn ON if the set value is changed as follows because of the use of a constant read-in system:

Elapsed time (UP) mode: Present value \geq Set value Remaining time (DOWN) mode: Elapsed time \geq Set value (The present value is set to 0.)

When in the remaining time mode, the amount the set value is changed is added to or subtracted from the present value. Operation with a set value of 0 will vary with the output mode. Refer to the timing charts on **page 20**.

H5CX-B□-N:

When changing the set value during a timing operation, the output will turn ON if the set value is changed as follows because of the use of a constant read-in system:


- 1. Forecast Value Setting
 - When the present value \geq the set value, OUT2 (control output) turns ON.
 - When the present value ≥ the forecast value (forecast value = set value forecast set value), OUT1 (forecast output) turns ON.
- 2. Absolute Value Setting
 - When the present value \geq set value 2, OUT2 (control output 2) turns ON.
 - When the present value ≥ the forecast value (forecast value = set value forecast set value), OUT1 (control output 1) turns ON.
 - When the set value is 0, the output turns ON the moment the signal is input. The reset operation turns OFF the output.
- Do not use organic solvents (such as paint thinners or benzine), strong alkali, or strong acids. They will damage the external finish.
- Confirm that indications are working normally, including the backlight LED, and LCD. The indicator LEDs, LCD, and resin parts may deteriorate more quickly depending on the application environment, preventing normal indications. Periodic inspection and replacement are required.
- The waterproof packing may deteriorate, shrink, or harden depending on the application environment. Periodic inspection and replacement are required.

Precautions for Correct Use

- H5CX models with a 24-VDC/12 to 24-VDC power supply use a transformer-free power supply method in which the power supply terminals are not isolated from the signal input terminals. If a nonisolating DC power supply is used, unwanted current paths may occasionally burn or destroy internal components depending on the wiring. Always check the wiring sufficiently before use.
- An inrush current of approx. 10 A will flow for a short time when the power supply is turned ON. If the capacity of the power supply is not sufficient, the Timer may not start. Be sure to use a power supply with sufficient capacity.
- Maintain voltage fluctuations in the power supply within the specified operating voltage range.
- When turning the power ON and OFF, input signal reception is possible, unstable, or impossible as shown in the diagram below.

Power (
		200ms	0 to 5	0 ms	5ms	0 to 500) ms
Ir	put	Impossible	Unstable	Po	ssible	Unstab	le Impossible

- To allow for the startup time of peripheral devices (sensors, etc.), the Timer starts timing operation between 200 to 250 ms after power is turned ON. For this reason, in operations where timing starts from power ON, the time display will actually start from 249 ms. If the set value is 249 ms or less, the time until output turns ON will be a fixed value between 200 and 250. The present value display will start from 250 ms. (Normal operation is possible for set values of 250 ms or more.) In applications where a set value of 249 ms or less is required, use start timing with signal input.
- Inrush current generated by turning ON or OFF the power supply may deteriorate contacts on the power supply circuit. Turn ON or OFF to a device with the rated current of more than 10 A.
- Make sure that all settings are appropriate for the application.
 Unexpected operation resulting in property damage or accidents may occur if the settings are not appropriate.
- Do not leave the Timer for long periods at a high temperature with output current in the ON state. Doing so may result in the premature deterioration of internal components (e.g., electrolytic capacitors).
- EEPROM is used as backup memory when the power is interrupted. The write life of the EEPROM is 100,000 writes.
 The EEPROM is written at the following times:
 - · When the power supply is turned OFF
 - When switching from Timer/Twin Timer Selection Mode or Function Setting Mode to Run Mode
- Dispose of the product according to local ordinances as they apply.
- Attach the front panel when using the Timer. The tabs in the middle
 of each of four sides secure the front panel to the main body. To
 remove the panel, widen the four tabs and pull the panel toward
 you. To mount the panel, fit all four tabs correctly into the grooves
 on the main body.



♠ Conformance to EN/IEC Standards

- When conforming to EMC standards, refer to the information provided in this datasheet for cable selection and other conditions.
- This is a class A product. In residential areas it may cause radio interference, in which case the user may be required to take adequate measures to reduce interference.
- H5CX-A□-N/-L□-N:

Basic insulation is provided between the power supply and input terminals. (No insulation is provided between the power supply and input terminals for the H5CX-□D-N.)

Basic insulation is provided between power supply and output terminals, and between input and output terminals.

- H5CX-B□-N:
- No insulation is provided between the power supply and input terminals.
- Basic insulation is provided between the power supply and output terminals.
- When double insulation or reinforced insulation is required, apply double insulation or reinforced insulation as defined in IEC 60664 that is suitable for the maximum operating voltage with clearances or solid insulation.
- Connect the input and output terminals to devices that do not have any exposed charged parts.

Terms and Conditions Agreement

Read and understand this catalog.

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

Warranties.

- (a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.
- (b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

Limitation on Liability; Etc.

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Suitability of Use.

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products.

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Performance Data.

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications.

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions.

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Note: Do not use this document to operate the Unit.

OMRON Corporation Industrial Automation Company

Kyoto, JAPAN Contact : www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD.
438B Alexandra Road, #08-01/02 Alexandra
Technopark, Singapore 119968
Tel: (65) 6835-3011 Fax: (65) 6835-2711

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-5037-2222 Fax: (86) 21-5037-2200

©OMRON Corporation 2009-2023 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

CSM_5_7

Cat. No. L111-E1-04 0423 (0709)